



1. *Critical Root Zone: Extends in all directions from trunk of tree to a distance equal to one foot per inch of trunk diameter at breast height.*
2. *Staging, storage, dumping, washing and operation of equipment is not permitted within the limits of the tree protection barrier, including during barrier installation.*
3. *Install all tree protection prior to commencement of construction and remove when directed by the Engineer. Maintain protection at all times.*
4. *For closely spaced groups of trees, place the tree protection barrier around the entire group.*
5. *Inspect trunk protection and tree quarterly to prevent girdling. Adjust bands to allow tree growth as needed.*
6. *See plans for any additional requirements or modifications within the tree protection area.*
7. *Place weather resistant sign every 50' along the barrier, with 6" minimum text height and provide text in English and Spanish. Sign should read " Keep Out Tree Protection Area".*
8. *Alternate tree protection systems approved by the Engineer may be used in lieu of the tree protection barrier detailed on this Index as long as the critical root zone is protected.*
9. *The Critical Root Zone may be reduced, in the field, by a certified Arborist or Landscape Architect.*



TREE PROTECTION AND PRESERVATION



= PROTECTION BARRIER FOR TREE GROUPINGS =



NOTES:

1. *Trunk protection may be used when Tree Protection Barrier can not be reasonably erected, when approved by Engineer.*
2. *See Selective Clearing and Grubbing Plan for location of trunk protection, when applicable.*
3. *Adjust bands to allow tree growth (inspect quarterly to prevent girdling).*

= TRUNK PROTECTION =

LAST REVISION 11/01/18	DESCRIPTION:  FY 2027-28 STANDARD PLANS	TREE PROTECTION AND PRESERVATION	INDEX 110-100	SHEET 1 of 1
------------------------------	---	----------------------------------	------------------	-----------------