



**GENERAL NOTES:**

1. AC wired cabinet shall be equipped with a surge protector with an alarm feature.
2. Equipment cabinet shall be located on DMS sign structure.

**LEGEND**

- ◆ — Data
- ■ — Ethernet
- — Power
- — TVSS Transient Voltage Surge Suppressor



2008 FDOT Design Standards

**DMS CABINET AND SIGN WIRING AND BLOCK DIAGRAM**

Last Revision 07/01/07	Sheet No. 1 of 1
Index No. <b>18300</b>	