



## GENERAL NOTES:

- 1. Contractor shall splice fiber optic cables in cabinet to preterminated patch panel.
- 2. Furnish and install TVSS protection on all cabling in cabinet.
- 3. Furnish and install secondary TVSS protection on outlets for equipment in cabinet.
- 4. Sizes and types of conduits and innerducts for network communications between the pull box and cabinet are stated in the contract documents.
- 5. Ensure that equipment cabinet is bonded to CCTV pole grounding system.
- 6. All network communications conduits and ducts shall be sealed with approved waterproof duct plugs and seals.
- 7. Pole mounted cabinets shall be mounted with hinges next to the pole.

LAST REVISION 07/01/07

≥ DESCRIPTION:

FDOT DESIGN STANDARDS