

## Index 444-t01 Deep Well Injection Box

### Design Criteria

*FDOT Design Manual (FDM); Drainage Manual (DM)*

### Design Assumptions and Limitations

Provide a casing depth of at least 60". Open Hole Depth is 10' – 20'.

Determine size of Inflow and Outflow chambers using Table 3 of **Index 425-010** and the size of the pipes. Provide a constant structure width, based on the largest pipe. Adjust length based on size and orientation of the pipes.

### Plan Content Requirements

Call out structure width on the Plans. For structures with adjusted length to accommodate size and orientation of the Pipes, call out the length on the Plans.

### Payment

| Item number | Item Description        | Unit Measure |
|-------------|-------------------------|--------------|
| 444-74      | Deep Well Injection Box | EA           |

See the **BOE** and **Specifications** for additional information on payment, pay item use and compensation.