

Index 520-005 Concrete Shoulder Gutter Spillway

Design Criteria

FDOT Design Manual (FDM); Drainage Manual (DM)

Design Assumptions and Limitations

Use in conjunction with Shoulder Gutter where inlets, pipes and endwalls are not practical.

Plan Content Requirements

If spillway empties into an unpaved ditch, the detail should be modified and included in the Plans.

Payment

Item number	Item Description	Unit Measure
520-6	Concrete Shoulder Gutter	LF

See the *BOE* and *Specification 520* for additional information on payment, pay item use and compensation.