

## NOTES:

- 1. L = Taper Length
- B = Buffer Length
- X = Work Zone Sign Distance

See Index 102-600 for "L", "B", "X", and channelizing device spacing values.

- 2. Optionally, use "Signal Ahead" signs with symbols (W3-3) instead of "Signal Ahead" signs with text (W3-3A).
- 3. Use temporary raised rumble strips in accordance with Index 102-603.
- 4. The "Speeding Fines Doubled When Workers Present" signs (TTC-011A-25) and "End Road Work" signs (G20-2), along with associated work zone sign distances, may be omitted when the work operation will be in place for 24 hours or less.
- 5. For the maximum distance between temporary traffic signals, do not exceed the distance at which the temporary traffic signals can safely communicate. When the distance temporary traffic signals is greater than 0.25 miles, use a combination of a pilot vehicle and manually-controlled temporary traffic signals.
- 6. Monitor temporary traffic signals by having one or more workers present during operation. In the event of a temporary traffic signal failure, use flaggers to control traffic.

## SYMBOLS:



■ Channelizing Device (See Index 102-600)

Work Zone Sign

Temporary Traffic Signal

Lane Identification and Direction of Traffic

DESCRIPTION: