

## **Index 000-510 and 000-511 Superelevation Transitions**

### **Design Criteria**

*FDOT Design Manual ([FDM](#)); AASHTO A Policy on Geometric Design of Highways and Streets*

### **Design Assumptions and Limitations**

*Indexes 000-510 and 000-511* provide requirements for installation of superelevation transitions on both low and high-speed highways. For superelevation criteria, see [FDM 210](#).

### **Plan Content Requirements**

See [FDM 915](#).

### **Payment**

No separate payment is made for superelevation.