

**HIGHWAY SIGNING.**  
**(REV 4-17-23)**

SUBARTICLE 700-3.1.5 is deleted and the following substituted:

**700-3.1.5 Retroreflective Strips for Signs:** Use with static Wrong-Way Signs in accordance with Standard Plans, Index 700-101 and on other signs where retroreflective strip is called for in the Plans. Use only on signs where the retroreflective strip is called for in the Plans. The retroreflective strip must be 2 inches in width and 5 feet in height for all signs, except for signs mounted at a height of 4 feet, then use a retroreflective strip 2 feet in height. For the back of Railroad Crossbuck signs, the retroreflective strip will be 2 inches wide for the full length of the blade. Match the color of the retroreflective strip to the background color of the sign (per the SHS), except for YIELD signs and DO NOT ENTER signs, where the color must be red. Install retroreflective strips directly to a panel attached to the column in accordance with the manufacturer's instructions. Use a 0.040-inch minimum aluminum plate or other material approved by the sheeting manufacturer. Use stainless steel attachment hardware for the installation. Install retroreflective strips in a manner that does not require drilling holes through the column (post). A set screw no larger than 1/4 inch may be used with band attachments.

DRAFT  
INTERNAL REVIEW