

EXPECTED IMPLEMENTATION JULY 2022

300 PRIME AND TACK COATS. **(REV 10-12-21) (FA 12-27-21) (7-22)**

SUBARTICLE 300-2.2 is deleted and the following substituted:

300-2.2 Cover Material for Prime Coat: Uniformly cover the primed base by a light application of cover material. The Contractor may use either sand or screenings for the cover material. For the sand, meet the requirements as specified in 902-2 or 902-6, and for the screenings, meet the requirements as specified in 902-5. If the primed base course will be exposed to general traffic, apply a cover material coated with 2 to 4% asphalt cement. Apply the asphalt coated material at approximately 10 pounds per square yard. Roll the entire surface of asphalt coated prime material with a traffic roller as required to produce a reasonably dense mat.

SUBARTICLE 300-3.1 is deleted and the following substituted:

300-3 Equipment.

300-3.1 Pressure Distributor: Provide a pressure distributor equipped with pneumatic tires having a sufficient width of rubber in contact with the road surface to avoid breaking the bond or forming a rut in the surface. Ensure the distance between the centers of openings of the outside nozzles of the spray bar is equal to the width of the application required, plus or minus two inches. Ensure the outside nozzle at each end of the spray bar has an area of opening greater than the opening of an interior nozzle by 25% to 75%. Ensure all other nozzles have uniform openings. When the application covers less than the full width, the Contractor may allow the normal opening of the end nozzle at the junction line to remain the same as the interior nozzles. A trailer-mounted pressure distributor can be used for non-mainline applications, if approved by the Engineer. It shall have a self-contained heat system, clean out system, calibration chart, manhole, and shall meet the requirements herein.

Clean the distributor tank at a minimum of every twelve months and whenever the product type in the tank is changed. Remove all emulsion and asphalt material during cleaning. Additionally, clean the distributor tank if the quality of the tack or prime shot diminishes or buildup causes the calibration of the tank to be affected.

SUBARTICLE 300-8.5 is deleted and the following substituted:

300-8.5 Curing and Time of Application: When using a distributor, apply tack coat sufficiently in advance of placing bituminous mix to permit drying, but do not apply tack coat so far in advance that it might lose its adhesiveness as a result of being covered with dust or other foreign material. When using a spray paver, the requirements above do not apply.