

630 CONDUIT-INSTALLATION REQUIREMENTS.
(REV 10-18-02) (FA 1-14-03) (7-03)

SUBARTICLE 630-3.1 (Pages 724 and 725) is expanded by the following:

630-3.1.1 Conduit For Fiber Optic Cable: Run an AWG #14 locate wire with the fiber optic cable in the conduit when installed underground. Do not run the locate wire into the cabinet. Terminate at the nearest pull box.

Exclude water and debris from the conduit and top riser assembly of above ground conduit by use of a foam-sealing material, rubber plug, or other device, designed for this type of application and approved by the Engineer. Use a flexible conduit UV rated to protect the cable from the top of the conduit riser to the span messenger where the cable is to be lashed.

SUBARTICLE 630-4.2 (Page 727) is expanded by the following:

Furnishing and installing the locate wire is included in the cost of the conduit.