

350 CEMENT CONCRETE PAVEMENT.

350-11 Curing.

350-11.1 General: After completing the finishing operations and as soon as the concrete has hardened sufficiently to not mar the surface, cover and cure the entire

of preventing displacement prior to placing of the concrete. Do not paint or coat the bars with any material before placing them in the concrete.

If placing tie bars along a longitudi

Cut the filler to the crown and

350-12.6.1.2 Non-Sawed Joints: Thoroughly clean joints which require sealing of all foreign material for the full depth of the seal installation.
With the exception of slurry

