

**STABILIZED SUBBASE UNDER CONCRETE PAVEMENT.
(REV 1-3-94) (7-00)**

ARTICLE 160-3 (Page 189) is expanded by the following:

When stabilized subbase is specified for use under concrete pavement, use shell commercial stabilizing material meeting the requirements of Section 913.

Backdump and spread the shell on the prepared subgrade to a depth of 4 inches loose measure and mix and compact to a final depth of 12 inches.

During paving operations, keep the subgrade in advance of the paving train (including track for paving train) at optimum moisture $\pm 1\%$.