

**676 CONTROLLER CABINETS – BASE MOUNTED CABINETS (TYPES 4, 5 AND TYPES USED FOR MODEL 170 CONTROLLER ASSEMBLIES).  
(REV 5-5-08) (FA 10-14-08) (7-09)**

SUBARTICLE 676-3.3 (Pages 715 and 716) is deleted and the following substituted:

**676-3.3 Base Mounted Cabinets (Types 4, 5, and types used for Model 170 controller assemblies):**

- (a) Use anchor bolts to fasten base mounted cabinets to the concrete base.
- (b) Seal the joint between the bottom of the cabinet and the concrete base (inside and outside of cabinet) with a clear silicone rubber sealant.
- (c) Construct the base for the cabinets with concrete in accordance with Section 347. Make the concrete base for the cabinet level, free of honeycombs and as smooth as possible. Temporarily seal the end of conduit risers located in the base before placing the concrete. Position the end of the conduit risers a minimum of 2 inches above the finished surface of the concrete base.