

FLT Geosystems

System 500 GPS

Reference Station Site Configuration

This guide assumes Network Rover settings in place and shows site creation or site changes only.


From the Main Menu, Press the CONFIG Key

SELECT (4) Interfaces



Highlight (1) Real-Time. Port should show current modem configuration

Select F5 CTRL for the Modem Connection Screen



Station Name Number are displayed.

Highlight Station field and press ENTER.




Select F2 NEW to create site
or
Highlight existing and select
F3 EDIT to change site



Enter Station Name and the
IP address and Port
or make changes

Select F1 CONT to proceed

F1 CONT until reaching
Main Menu



Begin Survey or Stakeout Operations.
Press SHIFT, then CONEC