



ADVANCE WARNING ARROW PANEL MODE . CAUTION

The Advance Warning Vehicle (Optional) may be used at the direction of the Engineer. If an Advance Warning Vehicle is operated within the travel way, an approved Truck Mounted Attenuator will be required on the Advance Warning Vehicle but not required on the Shadow Vehicle. The Advance Warning Arrow Panel and Warning Sign are required on both the Advance Warning and Shadow Vehicles.

WORK IN TRAVEL WAY

GENERAL NOTES

- I. Where work activities within 2' of the edge of travel way are incidental (i.e., Mowing, Litter Removal), the Engineer may delete requirements for signs and the advance warning vehicle provided vehicles in the work area have high-intensity rotating, flashing, oscillating, or strobe lights operating.
- 2. If an arrow panel is used, the caution mode shall be used.
- 3. Shadow and Advance Warning Vehicle shall display rotating/strobe lights.
- 4. For general TCZ requirements and additional information, refer to Index No. 600.

CONDITIONS

WHERE ANY VEHICLE, EQUIPMENT, WORKERS OR THEIR ACTIVITIES REQUIRE AN INTERMITTENT OR CONTINUOUS MOVING OPERATION.

Work Zone Sign

SYMBOLS

Work Area

Lane Identification + Direction of Traffic

Work Vehicle With Rotating/Strobe Lights

Orange Flag And Type B Light

Sign With 18" x 18" (Min.)

A DAW! Advance Warning Vehicle with Truck Mounted Attenuator (TMA)

2008 FDOT Design Standards

07/01/05

Sheet No. 1 of 1

607

TWO-LANE TWO-WAY, MOBILE OPERATIONS WORK ON SHOULDER, WORK WITHIN THE TRAVEL WAY