





## **GENERAL NOTES:**

DESCRIPTION:

- 1. Install sign assemblies based on Alpha-Numeric Type designation shown in the Plans (e.g., Type A1). Assembly Type is based on Power Configuration 'Alpha' Identification shown above and Numerical Identification shown on Sheet 3 thru 8.
- 2. Install sign panel and wind beam in accordance with Index 700-010 and Specification 700.
- 3. Engage all threads on the transformer base and post unless the aluminum post is fully seated into base.
- 4. Meet the requirements of Specification 646 for aluminum poles and transformer bases
- 5. Install a concrete slab around all flashing beacon assemblies on slopes 6:1 or greater. The minimum slab dimension is 4'-0" by 5'-0".
- 6. When wire entry holes are drilled in the sign column, use a bushing or rubber grommet to protect conductors.





POWER CONFIGURATION 'B' SOLAR-POWERED (Type B1 Shown)

## POWER CONFIGURATION 'B' NOTES:

- 1. Install a separate pole for mounting the solar panel, controller and batteries for all flashing beacon assemblies with solar panels, controllers and batteries weighing more than 170 lbs.
- 2. Install the auxiliary pole as close to the right of way boundary as possible. **CORRECTED:** Roadside
- 3. Install the auxiliary pole so that the height is the same as the column for the beacon assembly.
- 4. Orient solar panel to face South for optimal exposure to sunlight.
- 5. The controller and the solar batteries may be located in the same compartment.

TABLE OF CONTENTS:	
Sheet	Description
1	General Notes and Contents
2	Conduit, Wiring, and Foundation Details
3	Roadside Sign Assembly-1
4	Roadside Sign Assembly-2
5	Roadside Sign Assembly-3
6	Roadside Sign Assembly-4
7	Roadside Sign Assembly-5
8	Roadside Sign Assembly-6
9	Overhead Sign Assembly

**REVISION** 11/01/18

FDOT

FY 2019-20 STANDARD PLANS

INDEX 700-120

SHEET