

GRASSING (BY SEEDING) - WATERING.

(REV 3-10-00) (7-03)

SUBARTICLE 570-3.6 (Page 700) is deleted and the following substituted:

570-3.6 Watering: Provide a vehicle for applying water to the grassed areas equipped with either a calibrated tank or an approved metering device installed at such point on the vehicle to measure the water at time of application. Do not water newly seeded areas to force the seed germination. Do not apply more than 1 inch [25 mm] of water per week for sustaining the grass growth. Use water only on vegetated areas when permitted by the Engineer.