

PARTIAL VIEW A-A



PLAN VIEW STEEL PILE CAP ASSEMBLY
(Bearing Plates and Bearing Keeper Bars not show for clarity)



VIEW B-B



VIEW C-C
PILE TIP DETAIL



STRUT CONNECTOR PLATE DETAIL

10/6/2022 10:45:38 AM

LAST REVISION	REVISION	DESCRIPTION:			INDEX	SHEET
07/01/15			FY 2023-24 STANDARD PLANS	TEMPORARY DETOUR BRIDGE DETAILS STEEL PIPE PILE FOUNDATIONS	102-230	1 of 3



PARTIAL PLAN VIEW



PARTIAL ELEVATION VIEW



END VIEW

Note:
Use Shim Plates as required to provide equal bearing seat elevations across the bent. Vary thickness of Shim Plate across the pile cap plate to provide a level bearing area in the transverse direction.



FIXED BEARING KEEPER BAR DETAIL

10/6/2022 10:45:39 AM

FIXED BEARING DETAILS

LAST REVISION	REVISION	DESCRIPTION:			INDEX	SHEET
01/01/16			FY 2023-24 STANDARD PLANS	TEMPORARY DETOUR BRIDGE DETAILS STEEL PIPE PILE FOUNDATIONS	102-230	2 of 3



PARTIAL PLAN VIEW



PARTIAL ELEVATION VIEW



END VIEW

Note:
Use Shim Plates as required to provide equal bearing seat elevations across the bent. Vary thickness of Shim Plate across the pile cap plate to provide a level bearing area in the transverse direction.



EXPANSION BEARING KEEPER BAR DETAIL

10/6/2022 10:45:39 AM

ABUTMENT AND INTERMEDIATE EXPANSION BEARING DETAILS

LAST REVISION	REVISION	DESCRIPTION:			INDEX	SHEET
01/01/16			FY 2023-24 STANDARD PLANS	TEMPORARY DETOUR BRIDGE DETAILS STEEL PIPE PILE FOUNDATIONS	102-230	3 of 3