


- \*  $\frac{1}{8}$  Length (4' and 5' shoulder)  $\frac{1}{4}$  Length (2' shoulder)
- \*\*  $\frac{1}{4}$  Length (4' and 5' shoulder)  $\frac{1}{2}$  Length (2' shoulder)

INSERT A



- $\frac{1}{8}$  Length (4' and 5' shoulder)  $\frac{1}{4}$  Length (2' shoulder)
- \*\*  $\frac{1}{4}$  Length (4' and 5' shoulder)  $\frac{1}{2}$  Length (2' shoulder)

INSERT B

## NOTES:

- Bridges should be marked as narrow bridges under the following conditions:

   (1) For approach roadways with paved shoulders when the bridge width including shoulders is less than the width of the approach roadway including paved shoulders.
   (2) For approach roadways without paved shoulders when the bridge shoulder width is less than 2'.
- 2. Roadways with Two-Way Traffic:

  No passing zone should be extended 1570'in advance of narrow bridge.
- 3. If the bridge or the approach is on a curve, delineators shall be installed for a distance of 1570' in advance of narrow bridge on the outside portion of the roadway. Spacing shall be 100' between delineators.

  Delineators are to be placed not less than 2' or not more than 8' outside the outer edge of pavement.
- 4. Dbject markers and delineators on both sides of roadway shall face traffic approaching bridge
- 5. The DM-3R & DM-3L object markers shall be installed 4' above the roadway edge. The panels may be post mounted at the bridges.



2010 FDOT Design Standards

RURAL NARROW BRIDGE TREATMENT Last Sheet No. 07/01/09 2 of 2

17359