FDOT Driveway Subassembly

- *James Worley*
- *CADD APPLICATIONS DEVELOPMENT SPECIALIST*
- *Florida Department of Transportation*
- *Engineering/CADD Systems Office (ECSO)*
- *Email: James.Worley@dot.state.fl.us*

Engineering/CADD Systems Office

FDOT Driveway Subassembly

- First step is to place the dynamic block for driveways in your model.

- Make the needed design changes to the dynamic block.

- Trace the required lines, remembering to include elevation.

- Once all lines have been laid out, you can erase the block.

FDOT Driveway Subassembly

- Now you begin placing the needed components of your driveway.
- Start with either Curb and Gutter or Shoulder at the pavement edge.
- Driveways will always use Slab 1 and Slab 3 subassemblies.
- Slab 2 subassembly is only used when sidewalk is present.

FDOTTypeACurb

FDOTTypeECurb

FDOTTypeFCurb

FDOTDrivewaySlab1

FDOTDrivewaySlab2

FDOTDrivewaySlab3

FDOTConditionalHorizontalTarget

FDOTSidewalk

Engineering/CADD Systems Office

FDOT Driveway Subassembly

- Once you build your corridor you will be able to see the results.

FDOTSlab3

FDOTSlab1

FDOTSlab2

Engineering/CADD Systems Office

Thank you for attending and have a great Expo!

FDOT Driveway Subassembly

- *James Worley*
- *CADD APPLICATIONS DEVELOPMENT SPECIALIST*
- *Florida Department of Transportation*
- *Engineering/CADD Systems Office (ECSO)*
- *Email: James.Worley@dot.state.fl.us*

Centennial FDOT 1915 ★ 2015

Engineering/CADD Systems Office

2015 Design Training Expo