Revised: August 5, 2014 D Decker

Equipment Checklist FM 1-T 11 Total Materials Finer than 75-µm No. 200 Sieve

		Р	F	N/A		
Apparatus						
1.	Balance – The balance is sufficient capacity readable to 0.1% of the sample mass or better and conforms to M 231					
2.	Sieves – A nest of two sieves the lower being a No. 200 sieve, Top No. 16					
3.	Container – A pan or vessel of a volume at least two times the volume of the wash sample					
4.	Oven – Of sufficient size capable of maintaining a uniform temperature of 110 \pm 5 C (230 \pm 9 F)					
5.	Wetting Agent – Any dispersing agent such as liquid dishwashing detergents					
6.	FM 1-T 011 does not approve the use of a mechanical apparatus to perform the washing operation					

Remarks:

Date:	Technician:	IA Observer:					
Technician's E-mail Address:							
Employer's/Superv	visor's E-mail Address:						