



07/01/05




Profile 13

## Post-Tensioning Vertical Profiles for Staged Grouting


(Simultaneous Low Point Grouting through a Manifold is not Permitted)



Profile 14



Profile 15



Profile 16

## NOTES: Grouting Procedures

- 1. Take into account longitudinal grade, if any, and establish direction of grouting.
- 2. Orient end anchors so that grout outlet is at the top.
- 3. Provide grout outlets at all anchors.
- 4. Provide grout inlet at low point of all tendon profiles.
- 5. For tendons longer than 150 feet, additional grout outlets are required.
- 6. Incorporate the information on these drawings into the grouting operations plan.
- 7. In the grouting plan, show
- a. Direction of grouting
- b. Locations of grout inlets & outlets
- c. Staged grouting operations
- d. Sequence of opening & closing vents
- e. Procedures for time delayed grout phasing of the tendons.
- 8. After grouting, inspect all anchors and high points for voids.
- 9. Vacuum grout voids and seal post-tensioning system in accordance with the specifications.



Strand Tendon End Anchor with Grout Outlet

Grout Inlet

Grout Outlet

8

Optional Grout Outlet Drain / Optional Grout Inlet

Direction of Grout Flow Inspection Location

LAST REVISION 07/01/05



FDOT DESIGN STANDARDS 2013

POST-TENSIONING VERTICAL PROFILES

INDEX SHEET NO. NO. 21801

20'-0" Spacing of Intermediate Grout Ports

-Intermediate Grout

Inlet (Not to exceed 20')

Profile 17

-Low Point