Index 289 Concrete Box Culvert Details (LRFD) (Rev. 07/14)

Design Criteria

AASHTO LRFD Bridge Design Specifications, 6th Edition; Structures Design Guidelines (SDG)

Design Assumptions and Limitations

Designs for box culverts shown in this Index are to be produced only by computer analysis, utilizing the Department's *LRFD* Box Culvert Program. Designs are to be limited to the live loads and dimensional restraints shown in the General Notes of this Index and to the fill on the barrel(s), as shown in the Contract Plans.

Headwalls with skew angles less than -50° or greater than +50° require special design authorization. In these cases, other design options should be considered. Contact the District Drainage Engineer to obtain authorization.

At the contractor's option, Index 292 Standard Precast Concrete Box Culverts may be substituted for Index 289 cast-in-place box culverts unless specifically prohibited by a plan note. See also the Instructions for Design Standards Index 292.

Plan Content Requirements

In the Roadway or Structures Plans:

For box culvert extensions with skewed joints at the connection location, consider providing additional reinforcing parallel to the joint for the full width of the culvert to ensure proper load paths for transverse forces. Provide details for these additional reinforcing bars in the plans and manually add these bars to the reinforcing bar list.

Complete the following "Box Culvert Data Tables" and include them in the plans. See Introduction I.3 for more information regarding use of Data Tables.

Work these data tables with the FDOT MathCAD *LRFD* Box Culvert Program and Index 289. Include concrete and reinforcing steel quantities in the Summary of Quantities table.

Fill in tables using the "Include" Key-In Utility in MicroStation and line1.prn thru line6.prn files located in the program root directory.

Use Structures Site Menu>Text>Table Data, which uses "Chart_TTF" Text Style and True Type Font FDOT Mono.

Complete Notes 1 thru 8.

In Note 6 of the Data Table show Differential Settlement (ΔY) and Effective Length (L) for single curvature deflection where significant long-term settlement is anticipated and precast box culverts are not specifically excluded. See Index 291 (Sheet 5) for details. If precast box culverts are specifically excluded, delete Note 6.

If a box culvert extension is required, investigate the constraints and condition of the existing structure to determine whether a Type I and/or Type II Connection Detail is appropriate for each Structure/Bridge Number within the project. Contact the District Structures Design Engineer (DSDE) to obtain concurrence with the recommended Connection Detail. Based on concurrence from the DSDE, in Note 7 of the Data Table specify either "Type I", "Type II", or "Type I or Type II" for each Structure/Bridge Number within the project. If no box culvert extension is required, delete Note 7.

Type II Connections are generally less expensive and faster to construct than Type I Connections, but provide less longitudinal moment resistance. It is recommended that only Type I connections be specified when significant transverse settlement is anticipated under the extension, or when the face of the existing culvert headwall is severely damaged.

For box culverts meeting the definition of a bridge structure (See *PPM*, Volume 1, Chapter 33) include the Bridge Number in the plans and the Load Rating Sheet per *SDG* 3.15.14.

BOX CULVERT DATA TABLES BOX, HEADWALL AND CUTOFF WALL DATA TABLE (inches unless shown otherwise) able Date 7-01-09 STRUCTURE HEADWALL AND CUTOFF WALL LOCATION /BRIDGE HIcw Wc(ft)Hc(ft. Tb #cells Lc(ft) BIhw HIbw Brcw Hrcw SL(deg) SR(deg, NUMBER TtTwTiCover Brhw Hrhw Blow Table Date 01-01-11 LEFT SIDE WINGWALLS DATA TABLE (inches unless shown otherwise) STRUCTURE LEFT END WINGWALL LEFT BEGIN WINGWALL /BRIDGE SW(deg) β (deg) He(ft) Hs(ft) Lw(ft) Rt Rd SW(deg) β (deg) He(ft) Hs(ft) NUMBER Table Date 01-01-11 RIGHT SIDE WINGWALLS DATA TABLE (inches unless shown otherwise) STRUCTURE RIGHT END WINGWALL RIGHT BEGIN WINGWALL Rw Rh Hs(ft) Rt NUMBER Rt Rd SW(deg) β (deg) He(ft) Lw(ft) Rw Rh Rd $SW(deq) \beta (deq) He(ft) Hs(ft)$ Lw(ft) NOTES [Notes Date 7-01-14]: 1. Environmental Class ----2. Reinforcing Steel, Grade ----ESTIMATED CONCRETE QUANTITIES (CY) Table Date 7-01-13 3. Concrete Class ----- f'c = ----- ksi RIGHT END RIGHT BEGIN вох LEFT END LEFT BEGIN 4. Soil Properties: STRUCTURE WINGWALL WINGWALL WINGWALL WINGWALL Friction Angle ---/BRIDGE Right Right Sub Modulus of Subgrade Reaction ----Тор NUMBER Cutoff Cutoft Walls Head Head Slab Slab Total Wall ootin Wall Wall Wall Nominal Bearing Resistance ----Wall Wall Total Total Total Wall Wall Total 5. Work this Drawing with Design Standards Index No. 289 and Sheet Nos. ----6. Settlement criteria for Precast Box Culvert option (Index No. 291): Long Term Differential Settlement $(\Lambda Y) = ------ ft$. Effective Length for Settlement (L) = ----- ft. MAIN STEEL REINFORCEMENT SPACING (inches) Table Date 7-01-09 7. Connection Types permitted for Box Culvert Extensions: STRUCTURE вох HEADWALLS CUTOFF WALLS Structure/ Bridge Number XXXXX -(Type I/Type II/Type I or Type II) 101 102 103 104 105 106 107 108 109 110 112 113 114 803 806 809 812 NUMBER 111 8. Quantities for Type I and Type II Connections include 2 ft. additional payment length beyond Lc for connection to existing box culvert. (See Summary of Box Culvert Quantities box in Plans) WINGWALL STEEL REINFORCEMENT SPACING (inches) Table Date 7-01-09 LEFT BEGIN WINGWALL LEFT END WINGWALL RIGHT END WINGWALL RIGHT BEGIN WINGWALL STRUCTURE /BRIDGE 401 402 501 702 704 411 711 406 409 410 506 509 510 511 606 609 610 611 706 709 710 NUMBER 407(8) (403) 1405 507(8) (503) (505. 607(8 (603) (605) 707(8 (703) (705) WINGWALL NOTE: Bar designations in "()" are only required for variable height wingwalls

Payment

Item number	Item description	Unit Measure
400-2-1	Concrete Class II, Culverts	CY
400-4-1	Concrete Class IV, Culverts	CY
415-1-1	Reinforcing Steel - Roadway	LB