


ANGLED BICYCLE RAMP




STRAIGHT BICYCLE RAMP

TYPICAL PLACEMENT ON BICYCLE RAMPS


NOTES:

1. Construct Bicycle Ramp and locate Directional Tactile Walking Surface Indicator (Directional Indicator) as shown in the Plans. Extend Directional Indicators the full length of the bicycle ramp width.
2. Cut Directional Indicators to match skewed edges as shown.
3. Install Directional Indicators in accordance with Developmental Specification Dev528.
4. Panel lengths can vary based on vendor requirements and are not limited to three rows of raised bars as shown.
5. Panel widths can vary based on vendor requirements. Multiple panels can be placed side-by-side to achieve the overall 2'-0" width.


Dimension	Range (in.)
B1	0.70 to 1.00
B2	B1 + 0.40
C	0.35 to 0.60
G	0.45 to 1.20
H1	0.18 to 0.20
H2	0.12 Max.
L1	10.70 to 12.00
L2	L1 + 0.40



PLAN



SECTION A-A



SECTION B-B

DIRECTIONAL INDICATOR DETAILS

12/15/2020 9:12:25 AM

LAST REVISION	DESCRIPTION:
12/15/20	



DEVELOPMENTAL STANDARD PLANS

DIRECTIONAL INDICATOR

INDEX
D528-001

SHEET
1 of 1