

DISTANCE BETWEEN SIGNS				
Speed	Spacing (ft.)			
J Jpeeu	Α	В		
40 mph or less	200	200		
45 mph	350	350		

Table I					
Device Spacing					
Max. Distance Between Devices (ft.)					
Speed (mph)	Cones or Tubular Markers		Barricades or Vertical		
			Type I or Type II		
			Panels or Drums		
	Taper	Tangent	Taper	Tangent	
25	25	50	25	50	
30 to 45	25	50	30	50	

Table II Buffer Space and Taper Length					
Speed	Buffer Space	Taper Length (12' Lateral Transition)			
(mph)	Dist. (ft.)	L (ft.)	Notes (Merge)		
25	155	125			
30	200	180	$L = \frac{WS^2}{60}$		
35	250	245	$L = \frac{1}{60}$		
40	305	320			
45	360	540	L = WS		

When Buffer Space cannot be attained due to geometric constraints, the greatest attainable length shall be used, but not less than 200 ft.

For lateral transitions other than 12', use formula for L shown in the notes column. Where: L = Length of taper in feet W = Width of lateral transition in feet S = Posted speed limit (mph)

## CONDITIONS

WHERE ANY VEHICLE, EQUIPMENT, WORKERS OR THEIR ACTIVITIES ENCROACH ON THE PAVEMENT REQUIRING THE CLOSURE OF THE CENTER LANE NEAR AN INTERSECTION.

	INDEX	SHEET
CENTER LANE	NO.	NO.
	617	1 of 1